

Swan Systems Furniture Ltd

Unique Sliding Wardrobes & Matching Bedroom Furniture

Head Office, Showroom & Factory Address

Unit 6, The Tanneries, East Street, Titchfield, Hampshire, PO14 4AR
Tel: 01329 843 636 Fax: 01329 849 783

How to fit a Swan Systems Sliding Wardrobe CEILING DOWN-STAND

Every Swan Systems Sliding Wardrobe Door purchased from our on-line site comes with a Ceiling Down Stand. This is manufactured to fit precisely in your aperture dimensions provided and will ensure a perfect fit of the Swan Sliding Doors.

This guide makes the assumption that you have installed already the left and right hand side wall scribes and the laid the floor plinth and floor cill and all elements are level.

This example will be a finished aperture height of 2000mm with a ceiling height of 2118 to the high point (the point of the ceiling where your level will physically sit with the bubble in the middle)

You will be given your finished aperture height and width

1. Measure from the top of the plinth – 2000mm on the left and right hand scribe and mark with a pencil
2. Mark another line 18mm above the mark you have just made on both left and right hand scribe
3. Screw two brackets on each scribe facing the front of the sub-frame set back 23mm from the face. These should be positioned approx 20mm above the 2018 mark (last mark made) and the 2nd 20mm from the ceiling.
4. Using the top track as a straight edge between the scribes, fix the appropriate number of brackets to the ceiling set back 23mm from the face of the sub-frame and the face brackets the same way.
5. Cut the down stand to width
6. Pivot the down stand from the high point until level and temporarily fix the down stand level using the brackets
7. Take the measurement from the bottom of the down stand (nearest the plinth) to the 2018 mark on the Left hand and right hand scribe – if the plinth and down stand is level, they will both be the same
8. Using this figure, cut a block the same length
9. Take the block and scribe along the ceiling using a pencil. Run the pencil line between the scribes across the entire length of the down stand. This will give you an accurate reading of the ceiling.
10. Take down the ceiling down stand and cut along the line
11. Re-fit the down stand up to the entire length of the ceiling
12. Cut down stand return to size and fit on a 90 degree angle flush to the front of the scribes. Up and through the down stand and bracket as needed.
13. Fit top track, cut to size and trim