

Swan Systems Furniture Ltd

Unique Sliding Wardrobes & Matching Bedroom Furniture

Head Office, Showroom & Factory Address

Unit 6, The Tanneries, East Street, Titchfield, Hampshire, PO14 4AR
Tel: 01329 843 636 Fax: 01329 849 783

How to fit a Swan Systems Sliding Wardrobe SUB-FRAME

1. Measure from back wall on both sides and mark the depth of your wardrobe. When we fit we recommend a depth of 635mm and a minimum depth of 590mm.
2. Draw a level line from floor to ceiling, continuing over any skirting board, dado rail or coving
3. If cutting into coving and skirting board:
 - a. Skirting board will need to be marks 4mm in front (away from back wall) of original line to allow for trim. A 2nd line set back (nearest wall) 23mm from original line. The same process applies for dado rails
 - b. If you are cutting into coving, set original mark back by 1 ½ mm to allow for set-back. Draw a 2nd line set back 23mm (nearest wall). When cutting for trim at front , the size will vary depending on the size and angle of the coving. Offer the 25mm trim to the coving and mark accordingly.
4. Alternatively scribe around
5. Cut aluminium to size x 2, drill 5 x holes in the back and fix upright to walls along level line (side of nearest wall) and fix with appropriate fixings.
6. Cut scribes to size, cutting the waste from un-cammed end
7. Assemble scribes using male cams provided
8. Offer into aluminium channel and level
9. Fix through the back of the aluminium using screws provided with a 3mm pilot hole.
10. Remove backing from double sided tape attached to aluminium. Cut the 25mm trim to length and stick to aluminium as close to wall as possible
11. With left and right hand side level and fixed, cut the plinth to size
12. Check for pipes and screw plinth to floor; one screw to be used in the centre of the plinth every 200mm
13. Offer your level to the plinth and use the packers provided to find the level point over each screw hole
14. When level, take the spirit level away and place packers provided still in position parallel to the plinth on the inside of the wardrobe. Place the same number of packers, again in position and parallel with the plinth on the outside of the wardrobe
15. Unscrew plinth and lift. Place packers either side of each screw hole and screw plinth back down.
16. Double check plinth is level and stick bottom cill cut to length to plinth, 20mm back from face of plinth
17. Fit ceiling down stand and top track and soft close (see separate instruction sheet for this)
18. Fit pins for soft close on doors and soft close mechanism in track
19. To fit doors take back doors first and slot in top first on the back track. Check the doors are sitting properly on the bottom track avoiding the soft close mechanism
20. Repeat for front doors
21. Level doors using screw head on wheels, tighten to raise and loosen to drop

Please refer to the **ADVICE** section of our website to watch the above information in our series of short videos.